

Portable Filter Cart Model 110



The Model 110 specializes in applications with large contaminants. A filter-bag removes large particles before the COMO Filter polishes the fluid to any cleanliness level you desire. Each COMO Filter holds up to 20 pounds of dirt and 1 gallon of water, so you can extend fluid life and improve machine performance with fewer filter changes.

THIS PRODUCT FILTERS

- Cutting oil
- Grinding oil
- Diesel fuel
- Drawing oil
- Quench oil
- Hydraulic oil
- Gear oil
- Lube oil
- Many other industrial fluids

SPECIFICATIONS

- One C-1000 chrome-plated depth-filter housing
- One CB-400 chrome-plated bag-filter housing with basket
- 1 or 3 GPM iron gear pump with Buna-N mechanical seals
- 3/4 HP, 115 V, single-phase, 60 Hz, 1725 RPM, TEFC Motor
- Portable, chrome-plated frame with oil-resistant wheels
- Dimensions: 23" W x 24" x 46½" H
- Approximate weight: 175 lbs.

STANDARD FEATURES

- Pressure switch with high/low shut-off for unattended operation
- Fluid transfer feature to bypass depth-filter housing
- Gate valve for flow control
- Motor starter with thermal overload protection
- Power and pump indicator lights
- Pressure and vacuum gauge to monitor filter element & bag life
- Inlet wye strainer to protect pump

Don't let particulate & water contamination cause premature fluid breakdown. Improve performance and increase productivity by using the COMO Model 110.