

## Portable Filter Cart Model 120



The Model 120 is a turnkey filter cart designed for unattended filtration. With dozens of filter options, you can meet your exact cleanliness goals—as low as 1  $\mu\text{m}$  and 20 ppm water. Each COMO Filter holds up to 20 pounds of dirt and 1 gallon of water, so you can extend fluid life and reduce downtime with fewer filter changes than the competition.

### THIS PRODUCT FILTERS

- Hydraulic oil
- Gear oil
- Lube oil
- Turbine oil
- Transformer oil
- Engine oil
- Vacuum pump oil
- Fire-resistant hydraulic oil
- Many other industrial fluids

### SPECIFICATIONS

- Two C-1000 chrome-plated depth-filter housings
- 3, 5, or 7 GPM iron gear pump with Buna-N mechanical seals
- 3/4 HP, 115 V, single-phase, 60 Hz, 1725 RPM, TEFC Motor
- Portable, chrome-plated frame with oil-resistant wheels
- Dimensions: 23" W x 24" D x 46½" H
- Approximate weight: 175 lbs.

### STANDARD FEATURES

- Pressure switch with high/low shut-off for unattended operation
- Fluid transfer feature to bypass depth-filter housings
- Gate valve for flow control
- Motor starter with thermal overload protection
- Power and pump indicator lights
- Pressure gauge to monitor filter element life
- Inlet wye strainer to protect pump

Don't let particulate & water contamination destroy your oil and damage your machines.  
Reduce downtime and maximize productivity by using the COMO Model 120.

www.hubame.com.mx | marketing@hubame.com.mx | Teléfono (81) 8000 7600